Chromebook - How to do a hard restart

Make sure the student is signed out

Next hold down the following keys at the same time. This will ask if you would like to powerwash the computer. Please select yes.



Revision #2

Created Thu, Mar 11, 2021 6:24 PM by Michael Boxer

Updated Thu, Apr 1, 2021 3:35 PM by Michael Brown